

Pre Cut Kit Diagram

Part #FAK-204/12CB Cessna 208 Cargo Box 12mil

Installation Instructions

Use soap solution and lay film out on front of cargo box.

Align kit at top using this center point (1) as a guide

Use alcohol solution and tack down center section (2) vertically using your hard card

Apply alcohol solution to top corner of film (3) and painted surface. Stretch film to this corner, hold, and tack down.

Tack and squeegee out film around point (4)

Using your alcohol solution, stretch and tack film to position 5. Stretch out as many ripples as possible so they will be easier to work at the end.

Repeat on other side

Work out ripples with your hard card. Dry the edges as you go to promote adhesion. Use of a heat gun may help work out stubborn ripples, however be careful not to overheat film. If you have small ripples that won't go down you may trim them with a razor knife.

TIPS

*For best results install in a warm environment using a warm water solution. The warmth will help soften the film allowing it to stretch further. This thicker version of our protection film is more rigid and requires more pressure when stretching.

**Dry hands before stretching to ensure a good grip on the film

***Use recommended hard card for installation

****Replace as protective film becomes worn and abrasion damage is visible

